



AutoAnchor 730

QUICK USER GUIDE

IMPORTANT INFORMATION

READ BEFORE USING YOUR AUTOANCHOR

This User Guide is intended as a quick reference for day to day use of the AA730. It must be read in conjunction with the Owner's Manual. The Owner's Manual has installation, set up and testing instructions plus information relating to troubleshooting and maintenance. If you do not have the Owner's Manual please contact your supplier or the manufacturer for a copy.

USER PRECAUTIONS

It is the owner's sole responsibility to ensure the AutoAnchor is installed, used and maintained in a manner that will not cause accidents, personal injury or property damage. When using the AutoAnchor the operator must follow safe boating practices for all equipment use. The AutoAnchor manufacturer and supplier accept no liability for personal injury or property damage resulting from failure to follow the installation and operating instructions or the use of the AutoAnchor in a way that may cause accidents or damage or that may violate the law.

- **all equipment controlled by the AutoAnchor must be installed and used strictly according to the original equipment manufacturer's instructions;**
- **only persons who are fully aware of the correct use of the thruster, windlass, auxiliary or optional equipment should be allowed to use the AutoAnchor to control this equipment;**
- **the user must personally control and supervise all anchoring, docking and other equipment operations;**
- **the user must have a clear view of all equipment when operated using the AutoAnchor;**
- **the user must know the location of the main breaker or battery switch to disconnect the windlass, thruster or auxiliary equipment from all power sources in the event of an emergency;**
- **the power supply to all equipment must be turned off when it is not in use;**
- **there must be an alternative method available to operate all equipment to be operated by the AutoAnchor, including the windlass, thruster, auxiliary and optional equipment.**

WHEN CONTROLLING A WINDLASS


- maintain a clear view of the windlass, rode and/or anchor, plus any optional or auxiliary anchoring equipment during windlass operation;
- always ensure the anchor is fully docked and secured before moving the boat.

WHEN CONTROLLING A THRUSTER


- do not operate close to swimmers, the powerful suction of water could cause serious injury;
- never run the thruster out of the water, this can cause serious damage to the motor;
- running a thruster without resistance from the propeller can also cause serious damage to the motor;
- if the thruster stops giving thrust while the motor is running, turn it off immediately.

USING THE AA730 SYSTEM

INFORMATION DISPLAYED DURING OPERATION



AA730 BUTTONS




TO CONNECT THE CONSOLE FOR USE

- Unscrew the sealing cap on the deck socket.
- Fit the plug into the socket ensuring the pins are aligned correctly.
- Turn clockwise to lock.
- Switch on the power supply .
- Use the system as set up.
- When finished unscrew the plug from the socket.
- Replace the sealing cap and return the console to the cradle.

TO TURN THE AUTO ANCHOR ON

- Power up the AA703 base station. Press the Mode button to turn the remote console on. The screen will be locked and will display the last mode operated.



TO TURN THE AUTO ANCHOR OFF

- In the start screen press the Mode button to display the menu.
- Scroll to Off.
- Select Off.

OR

- Press and hold the MODE button for 6 seconds.




Note: The AA730 remote console automatically turns off after 5 minutes without use.

LOCK



Hold the Mode button for 2 seconds to unlock. The AA730 automatically turns off and resets the lock after 5 minutes without use.



To reset the lock manually:



Press the Mode button to display the menu.




Select Lock. The screen will return to the current mode with the lock on.



CHANGING MODES



Cycle through the modes by pressing the Mode button for 1 second at a time



OR

Press and release the mode button to access the Menu.



Select the Mode.



SET UP AND TESTING

Before use the AutoAnchor must be correctly set up for the equipment it is to control and then tested in a safe environment. For example, the AutoAnchor will not count correctly if the windlass selection is wrong or the windlass is not standard (eg it is installed with a different chainwheel or motor).

WINDLASS OPERATION WITH THE AA730

WHEN CONTROLLING A WINDLASS

- maintain a clear view of the windlass, rode and/or anchor, plus any optional or auxiliary anchoring equipment during windlass operation;
- always ensure the anchor is fully docked and secured before moving the boat.

PLUG & PLAY SENSOR TUNING

This screen automatically displays on first use. If Factory Defaults are loaded, the sensor is reset or there has been a loss of sensor signal. Required for all sensors other than a motor driven reed sensor.


Installation and set up must be complete and the anchor must be docked before starting this process.

Clear the AutoAnchor to zero if necessary. See page 6. Deploy the anchor using the AutoAnchor. Initially the status bar will display “**Sensor tuning**”. Continue deployment until this message changes to “**Tuning done**”. **This must be done in one continuous operation without taking your finger off the button until the “Tuning done” message displays. This could take up to 10 turns of the windlass.** Retrieve the anchor to the docked position and clear to zero if needed.



Note: If you do need to take your finger off the button, start the process again.

Rope/Chain System: The default rode set up is chain only. If rope and chain rode is selected without the correct sensor and magnet set up a “Sensor installation not compatible with rope and chain setting” message will display. Check the installation and rode set up and reset the sensor to restart the tuning process.



AUTOMATIC AND MANUAL WINDLASS OPERATION

Keep your finger on the button to deploy the anchor manually or use the automatic function for hands free anchor deployment and retrieval. See the instructions for both options below.

Note: The AA730 remote console automatically turns off after 5 minutes without use.

For an accurate reading always ensure the AA730 display reads 0.0 before deploying the anchor. See Clear to Zero on page 6.



Counting continues if the AA730 remote console is turned off and if the windlass is operated by another control eg foot switches.

MANUAL WINDLASS OPERATION

Deploy and Retrieve the Anchor Using Manual Operation



Turn the AA730 on.



Clear the safety lock.



Press and hold the up or down button to deploy or retrieve the anchor. Releasing the button stops the windlass operation.

Ensure the anchor is fully docked and secured before moving the boat.

DOCKING ALARM: During retrieval the windlass will stop and the AA730 beeps to warn the operator the anchor is at the preset docking distance. Press and hold the button to continue retrieval. If the system has been set up for dual speed. It will change to slow at this point. **Extra care must be taken at this stage of retrieval.**

AUTOMATIC WINDLASS OPERATION



WARNING: There is an inherent risk when using any automatic function on a boat. If you choose to use the AA730 automatic functions, you must still control and supervise all windlass and anchoring operation.

Use the Automatic Function to:

- Preset the length of rode for deployment;
- Have hands-free operation of the windlass;
- Retrieve the anchor automatically to the preset docking distance.

Note: For rope/chain counting, if the sensor or load sensing wires are not installed correctly the automatic function **will not operate**. An Installation warning message will display on the screen. The windlass can still be operated using manual operation but the AutoAnchor will not count accurately.







Safety Override



Press any button on the AA730 to stop the windlass during automatic release or retrieval. In an emergency shut off the power to the windlass using the isolating/breaker switch.

Enable Automatic Operation

A “rode to be released” value must be entered to use automatic operation.





4.5.4.3 To Set A Rode to be Released Value


-  Turn the AA730 on.
-  Clear the safety lock.
-  Press the Mode button to enter the menu.
-  Press the Mode button twice to enter Set auto.
-  Scroll up or down to the value.
-  Save and return to start screen.






To disable automatic operation: Set the rode to be released value to Off.

Deploy the Anchor Using Automatic Operation

-  Turn the AA730 on.
-  Clear the safety lock.
-  Press the Mode button to enter the Menu.
-  Press the Mode button again to select Auto. The screen displays the current length for Auto release. If this setting is correct, press and release the down button to deploy the anchor.









To Change the Setting:


-  Press the Mode button again to select Set auto.
-  Scroll to the value.
-  Save and return to Auto.



The windlass will stop and the AA730 will beep when the preset length of rode has been released. The screen will display “Target reached”.

Retrieve the Anchor Using Automatic Operation

-  Turn the AA730 on.
-  Clear the safety lock.
-  Press the Mode button to enter the Menu.
-  Press the Mode Button again to select Auto.
-  Press and release the Up button to retrieve the anchor. The windlass will stop and the AA730 will beep when the docking distance is reached. The screen will display Docking distance. If the system is set up for dual speed, it will change to slow speed at this point.
-  Press and hold the Up button to complete retrieval of the anchor. The AA730 will beep during this process.



Ensure the anchor is fully docked and secured before moving the boat.

USING DUAL SPEED

You must have a windlass with a dual speed motor to use this feature. **Default Speed is slow.**

▷ Use the right arrow to toggle between fast and slow speed. The current speed is displayed on the screen SL or FS.

If using Auto Mode select fast speed prior to selecting Auto.

The windlass automatically changes to slow speed when the docking distance is reached.

OTHER WINDLASS OPERATION SETTINGS

TO CLEAR TO ZERO

The AA730 must be turned on.



Press to access the Menu.



Scroll to Clear to Zero.



Select Clear to zero.



Select No/Yes.





Yes - return to start screen.



No - return to the menu, then press ◀ again to return



to the start screen.



TO CHECK LOGS

The AA730 must be turned on.



Press to access the Menu.



Scroll to Logs.




Select Logs.



Return to the menu.



Exit and return to start screen.



Logs can be cleared if base station is reset.

TO RESET SENSOR

The AA730 must be turned on.



Press to access the Menu.



Select Reset sensor.



Select No/Yes.




Yes - return to start screen.



No - return to the menu, then press ◀ again to return

to the start screen.

Deploy the anchor to tune the sensor. See page 3.



THRUSTER OPERATION WITH THE AA730

The AA730 can control a single bow thruster or a bow and stern thruster together.








USER PRECAUTIONS


Note: The AA730 remote console automatically turns off after 5 minutes without use. There must be an alternative means of controlling the thruster installed on the boat.

Only persons who are fully aware of the requirements for safe operation of the thruster should be allowed to use the AA730 to operate this equipment. The owner of the boat must take responsibility for ensuring the thruster is used according to the manufacturer’s instructions and with the appropriate safety precautions.


The thruster must not be operated close to swimmers, the powerful suction of water could cause serious injury. Never run the thruster out of the water as this can seriously damage the motor. Running a thruster without resistance from the propeller can also cause serious damage to the motor. If the thruster stops giving thrust while the motor is running, turn it off immediately. Always turn off the power to the thruster when it is not in use.

TO ACCESS THE THRUSTER


-  Turn the AutoAnchor on.
 -  Clear the safety lock.
 -  Cycle through the modes by pressing the Mode button for 1 second at a time
- OR**
-  Access the Menu.
 -  Select “Select Mode”.
 -  Scroll to Thruster.
 -  Select Thruster.



THRUSTER SYSTEM LOCKS




AA730 System locked.
Hold Mode button to clear.




Local lock on. No access from AA730.
Thruster operated by another controller.

SINGLE BOW THRUSTER OPERATION


- ◀▶ Use the left and right arrow buttons to control the thruster operation. Left to port and right to starboard.



Bow thruster selected.
System powered up and idle.



Thrust to port.




Thrust to starboard.


COMBINED BOW AND STERN THRUSTER OPERATION

- △ If there is a bow and a stern thruster fitted, use the up button to toggle between the bow thruster and the combined bow and stern thruster.
- ▽ Use the down button to toggle between the stern thruster and the combined bow and stern thruster.
- ◀▶ Use the left and right arrow buttons to control the thruster operation to port and starboard.


Dual Thruster Operation



Bow and stern thrusters selected. System powered up and idle.




Bow and stern thrusters to port.




Bow and stern thrusters to starboard.


Bow Thruster Operation



Bow thruster selected.
System powered up and idle.




Bow thrusting to port.




Bow thrusting to starboard.

Stern Thruster Operation



Stern thruster selected.
System powered up and idle.



Stern thrusting to starboard.




Stern thrusting to port.

Pivot (360° Turn) Operation

Pivot mode can be selected from any thruster operation mode, by pressing the Up button for more than 1 second. For example:


Bow thruster selected. System powered up and idle.



- △ Hold the Up button for more than 1 second to change to Pivot Mode.



- ◀▶ Use the left or right buttons to turn the boat clockwise or anticlockwise.




Clockwise.




Anticlockwise.

- △▽ To exit pivot mode and return to single thruster operation press the up or down button.

- △ Press the up button to return to bow thruster operation.



- ▽ Press the down button to return to stern thruster operation.



AUXILIARY EQUIPMENT OPERATION WITH THE AA730




The AA730 can control other equipment on the boat such as pumps, davits or cleats using the auxiliary outputs.



USER PRECAUTIONS

Only persons who are fully aware of the requirements for safe operation of the auxiliary equipment should be allowed to use the AA730 to operate this equipment. The owner of the boat must take responsibility for ensuring the equipment is used according to the manufacturer’s instructions and with the appropriate safety precautions.






Note: The AA730 remote console automatically turns off after 5 minutes without use.


TO ACCESS THE AUXILIARY MODE

-  Turn the AA730 on.
-  Clear the safety lock.
-  Depending on the system set up. Cycle through the modes by pressing the button for 1 second at a time.



OR


-  Tap to access the Menu.
-  Scroll to “Select Mode”.
-  Select “Select Mode”.
-  Scroll to Auxiliary outputs.
-  Select Auxiliary outputs.



On the console use the key shown on the screen to operate the Auxiliary output. The Auxiliary output will be highlighted on the screen when it is active.

M = Momentary
T = Toggle

Auxiliary Key References



FCC, CE and compliance statements are set out in the Owner's Manual

To the best of our knowledge the information in this User Guide was correct at the time of printing. However, the AutoAnchor is continuously being reviewed and improved and product specifications may be changed without notice. The latest product specifications may not be reflected in this version of the manual.

Documentation relating to the AutoAnchor is created in the English language and can be translated from English to another language. In the event of any conflict between translated documents, the English language version will be the official version.

All AutoAnchor documents including the Owner's Manual are also available on the website www.autoanchor.co.nz

The AutoAnchor is designed and manufactured by:

Kiwi Yachting Consultants Limited

PO Box 90114, Victoria St, West Auckland 1142, New Zealand

Phone: +64 09 360 0300 Fax: +64 9 360 0302 Australia: 1800 201 853

Email: sales@autoanchor.co.nz Web: www.autoanchor.co.nz