


GEN 4 FF12

FITTING INSTRUCTIONS



TEMPLATE MUST BE PRINTED AT 100% PAGE SIZE DO NOT SCALE

DO NOT USE ACETONE ON THIS PRODUCT

FF12 Fitting Instructions

1. Determine location of lights
2. Using this template mark and drill mounting holes
3. For thru-hull cable entry, mark and drill holes as per template
4. Apply generous amount of sealant to cable entry and screw holes
5. Using a hand screwdriver and screws provided fix lights to vessel HAND TIGHTEN ONLY
6. Connect Red to + and Black to - then to a switched and fused 12 or 24 Volts DC power source

(Fuse size will be determined by number of lights - allow 2 amps per light @ 12 Volts DC)