



FF12 Fitting Instructions

1. Determine location of lights
2. Using this template tot mark and drill mounting holes
3. For thru-hull cable entry, mark and drill holes as per template
4. Apply generous amount of sealant to cable entry and screw holes
5. Using a hand screwdriver and screws provided fix lights to vessel **HAND TIGHTEN ONLY**
6. Connect Red to + and Black to - then to a switched and fused 12 or 24 Volts DC power source

(Fuse size will be determined by number of lights - allow 1.5 amps per light @ 12 Volts DC)

**MUST BE PRINTED AT 100% PAGE SIZE.
DO NOT SCALE**