


REMOTE CONTROL KIT




REMOTE

FLOATING KEYRING

2 MOUNTING SCREWS


RECEIVER



RECEIVER

- BLUE – ANTENNA
- BLACK – NEGATIVE
- RED – POSITIVE
- WHITE – UP
- YELLOW – DOWN

ASSEMBLY



NEGATIVE TO NEGATIVE
ON SOLENOID

POSITIVE TO POSITIVE
ON SOLENOID

RED ON SWITCH
IS UP

COMBINE WHITE WITH
UP ON SOLENOID

BLACK ON SWITCH
IS DOWN

COMBINE YELLOW WITH
DOWN ON SOLENOID

PLEASE NOTE: To synchronise the remote to the receiver you must press both buttons at the same time for 5 seconds.